

# **ERSARE** VP6 ASSEMBLY INSTRUCTIONS

Hardware included:





### Step 1:

Lay out poles in correct shape and fasten in screws to connect the poles together.

#### Step 2:

Screw in wheels to the bottom of the frame.

## Step 3:

Add the canvas exterior using Velcro attachments around the poles.

## Step 4:

Screw in the wheels to the bottom of the panel.





